

TABELA DE MANCAIS MWM

Modelo \ NºCilindros	1		2		3		4	
	Qtd		Qtd		Qtd		Qtd	
KD 12	1	Biela - BB-048 / CBA32	2	Biela - BB-048 / CBA32	3	Biela - BB-048 / CBA32	4	Biela - BB-048 / CBA32
	1	Mancal - M-106 / KCF54F	2	Mancal - M-106 / KCF54F	2	Mancal - M-107 / KCF56F	2	Mancal - M-107 / KCF56F
					1	Mancal - M-108 / LCF03F	1	Mancal - M-108 / LCF03F
KD 112	1	Biela- BB-048 / CBA32	2	Biela- BB-048 / CBA32	3	Biela - BB-048 / CBA32	4	Biela - BB-048 / CBA32
	1	Mancal - M-106 / KCF54F	2	Mancal - M-107 / KCF56F	2	Mancal - M-107 / KCF56F	2	Mancal - M-107 / KCF56F
			1	Mancal - M-109 / LCF02F	1	Mancal - M-108 / LCF03F	1	Mancal - M-108 / LCF03F
D 222	1	Biela - BB-048 / CBA32	2	Biela- BB-048 / CBA32	3	Biela - BB-048 / CBA32	4	Biela - BB-048 / CBA32
	1	Mancal - M-106 / KCF54F	2	Mancal - M-107 / KCF56F	1	Mancal - M-107 / KCF56F	1	Mancal - M-107 / KCF56F
			2	Mancal - M-109 / LCF02F	1	Mancal - M-108 / LCF03F	1	Mancal - M-108 / LCF03F
					1	Mancal - M-257 / LCFA87F	1	Mancal - M-257 / LCFA87F